



Flexible Arches



PRICE LIST

[Online Order Form Flexible Arches and Flexible Mouldings](#)

Description	House Lot Price	List Price
Up To 36"	\$119.00	\$169.00
37" - 48"	\$129.00	\$179.00
49" - 60"	\$139.00	\$199.00
61" - 72"	\$149.00	\$219.00
73" - 84"	\$159.00	\$229.00
85" - 96"	\$169.00	\$249.00
97" - 108"	\$189.00	\$269.00
109" - 120"	\$199.00	\$289.00
121" - 132"	\$209.00	\$299.00
133" - 144"	\$219.00	\$319.00

Add \$50.00 for elliptical arches.



Job Site Made Arches

Measure the horizontal width of your opening. This will be the maximum width of your arch. Record this number.

Hold a tape measure across the opening. Keeping the ends of the tape level, slowly move it up until you see the measurement decrease. Move the tape back down to the point where it returns to your measurement from step one. This is the point where your arch begins to curve. Mark this point.

Measure the height from this point to the top centre of your opening. This measurement is the height of your arch.

You now need to add the reveal to your measurements. Add this once to the height and twice to the width (once for each side).

For Manufactured Doors & Windows

For manufactured windows, these measurements are all you need. For any non-machined arches,

you will need to include a template. Trace your arch on heavy paper, Bristol board, or cardboard. This will allow us to match the shape of you arch. *If you want arches for both sides of a doorway, please provide two well-labelled templates. This is important, as measurements are usually different on each side of a doorway constructed on the jobsite.



1021 College Road, Valley, Nova Scotia, B6L 3G6

1-800-419-1021

©2010 Vintage Mouldings Manufacturing Ltd..All rights reserved