



## **Installing A Vintage Mouldings Ceiling Medallion**

Apply a ¼" bead of premium paintable super latex caulk to perimeter of the back surface of the medallion.

Press medallion in place and fasten with three trim head screws. The screws should be placed such that their recessed heads can be easily filled and blended. Use trim head drywall screws or galvanized nails. Screw will self-countersink. We recommend placing the screws into an area with little ornamentation. It becomes easier to fill and sand the screw holes and the holes are less likely to be noticeable. Use a paintable, non-shrinking latex filler to fill the screw holes and sand the filler using fine sandpaper.

Paint with high quality latex or oil paint.



1021 College Road, Valley, Nova Scotia, B6L 3G6

1-800-419-1021

©2010 Vintage Mouldings Manufacturing Ltd. All rights reserved