



## **Installation & Finishing Instructions For Ultra High Density PolyPlaster**

The installation of PolyPlaster is very similar to the installation of wood mouldings. It can be cut, nailed, glued and screwed. However, it is lighter than wood and won't rot, warp or mildew and cannot be harmed by insects. Polyurethane may burn when exposed to flame. It is the purchaser's responsibility to ensure that products conform to local building codes.

### **Planning**

Have all necessary tools and equipment assembled. Be sure you have tested the adhesive on your working surface. PL Premium will stick to almost anything, in a case where it won't, testing will have to be done to determine an acceptable alternative that will adhere to both surfaces.

### **Interior & Exterior**

All PolyPlaster mouldings can be used indoors. PolyPlaster mouldings can be used outdoors after being painted with a good quality paint to protect them from the effects of ultra violet rays. Moisture will not harm the product and it will not rot or be affected by insects.

### **Cutting**

Use a sharp fine-toothed handsaw, table saw or circular saw. Trimming can be done with a sharp knife. If cutting large crowns or frieze boards that exceed the capacity of your power tools we suggest making an oversized mitre box from scrap material. Like wood, polyurethane will expand & contract slightly. We recommend that linear mouldings are cut approximately ¼" longer and sprung into place. We recommend that lengths of moulding be cut 1/16" to 1/8" longer and that they be sprung into place during installation.

### **Attachment**

Use Bull Dog PL Premium polyurethane adhesive or fast acting epoxy. Use trim head drywall screws or galvanized nails. Screw will self-countersink. Fill all holes with any exterior putty or fast drying automotive body fill and sand flush. Use the same adhesive when joining several pieces.

### **Prime and Paint**

All mouldings are supplied preprimed. Any exposed cuts should be covered with an ultra violet protected primer (many primers are). Any good quality interior or exterior acrylic paint as required may be applied as a finish coat. Do not let cut surfaces remain exposed to the sunlight.

*Vintage Mouldings warrants that its products are free from defects in material and workmanship for a period of one year from date of purchase. This warranty does not cover labour, transportation costs, damage or other expenses of any kind incurred with the sale or use of these products. A return authorization must be obtained from Vintage Mouldings head office. Polyurethane may burn when exposed to flame. It is the purchaser's responsibility to ensure that products conform to local building codes.*



1021 College Road, Valley, Nova Scotia, B6L 3G6

1-800-419-1021