



Weathermaster Installation Instructions

As with any exterior wood product ensure the adhesive used is intended for outdoor applications.

WeatherMaster is weather resistant and preprimed when it leaves our location. Cut edges should be primed on site.

Your mouldings must be primed and painted before being exposed to exterior applications.

Step 1) Apply a coat of high quality oil or latex paint.

Step 2) Install using an air nailer (we use a Senco Air Nailer or a Campbell Hausfield 3/8" - 1 1/4" 18-ga brad nailer) or pre-drill and nail. Use 18 gauge nails.

Step 3) After the installation of the mouldings, counter sink and fill all nail holes with exterior latex wood filler and allow to completely dry. There will be no counter sinking required if an air nailer was used.

Step 4) Sand all wood filler completely flat. Use of a flat block as a backer on flat areas and a piece of dowel, of approximately the same size as the curve in the moulding, can be used to maintain the profile.

Step 5) Repaint the face of all mouldings with a final coat of high quality paint



1021 College Road, Valley, Nova Scotia, B6L 3G6

1-800-419-1021

©2010 Vintage Mouldings Manufacturing Ltd. All rights reserved